
Spare parts list

Position	Description	No.
1	Left screw (for drill chuck)	407387
2	Drill chuck	407380
9	Gear	407382
16	Armature	407390
17	Carbon brush holder	407389
18	Carbon brush (set)	407386
22	Field coil	407391
26 + 27	Side handle	407388
31	Switch	407384
37	Chuck key	407381

Exploded view

