
Spare parts list

No.	Description	No.
409430	Switch	5
409452	Stator	17
409438	Rotor	25
409432	Dust connector	29
409433	Gear	41
409434	Flange (set)	047, 049 till 051
409450	Socket head screw	51
409435	Parallel guide	60
409436	Spanner (set)	61,62

Exploded view

