
Spare parts list

No.	Description	No.
408258	Base plate	15
408216	On/off switch	20
408259	Carbon brush (set)	22
408215	Speed adjuster	23
408260	Dust bag	30
800607	Bearing 607 ZZ	4
806000	Bearing 6000 ZZ	6

Exploded view

