



PARTS LIST

PARTS #	Description	PARTS #	Description
1	Screw	32	Washer
2	Washer	33	Screw
3	Left shell	34	Input plug
4	Spindle sleeve	35	Control plug
5	Gear #1	36	Handle
6	Gear #2	37	Nut
7	Cotter pin	38	Bolt
8	Shaft	39	Battery clamp
9	Union shaft	40	Remote control
10	Motor	41	Hook
11	Nut	42	Gear #4
12	Bolt	43	Spindle
13	Clamp	44	Gear #5
14	Frame	45	Frinction disc
15	Cable spring plate	46	Disc plate
16	Back plate	47	Clutch driving handle
17	Cotter pin	48	Nut
18	Pisition shaft	49	Crank handle
19	Bearing	50	Circuit breaker
20	Plate	51	Washer
21	Cable Plate	52	Screw
22	Shaft sleeve	53	Bolt
23	Cable shaft	54	Washer
24	Cable plate B1	55	Nut
25	Cable plate B2	56	Base plate
26	Gear #3	57	Nut
27	Washer	58	Washer
28	Washer	59	Spring
29	Nut	60	Ratchet
30	Right shell	61	Ratchet shaft
31	Nut	62	Cotter pin